



Step 1

- Remove the aluminium outer bag without damaging the clear inner bag.
- Immediately use the resin after opening the aluminium outer bag.

Attention:

- Do not mix different types or brands of resins.
- Take steps to prevent damage as a result of spilling resin.
- Wear disposable gloves and process only in a well ventilated room.



Step 2

- Remove the separator from the centre of the bag.



Step 3

- Mix contents by kneading vigorously for at least two minutes.
- Make certain all the resin compound is squeezed from the corners and edges of the bag.



Step 4

Pouring of the resin:

- Push all the resin to one half of the bag.
- Cut a small edge from the bag.
- Carefully pour the resin into the joint shell.
- Empty (hardened) resin packs can be disposed as regular waste material.